



# **Ceramic Spheres Derived From Cation Exchange Beads**

**Fred Dynys**


**National Aeronautics & Space Administration**

**Glenn Research Center**

**Sponsored: Ultra Efficient Engine Technology (UEET)**



# Thermal Barrier Coating



## Benefits:

- Reduce Substrate Temp. (150° F to 325° F )
- Increase Combustion Temp.
- Increased part life
- Environmental Protection
- Increase efficiency


## Ultra Efficient Engine Technology (UEET)

- Reduce  $\text{CO}_2/\text{NO}_x$  emission by increasing engine operating temperature  $\rightarrow 3000^\circ\text{F}$  (1649 °C)

## Radiation Barrier Coating

- Porous Coating to Reduce Photon Conduction
- Max. Scattering -Pores  $\rightarrow 1\text{-}4\ \mu\text{m}$
- Hollow/Porous Ceramic Spheres

## Blackbody





## **Objective**


**Establish a simple templating process to produce hollow ceramic spheres with a pore size 1 to 10  $\mu\text{m}$ .**

**Template – Cation exchange beads -Polystyrene based polymer**

**Oxide –  $\text{ZrO}_2$ ,  $\text{Y}_3\text{Al}_5\text{O}_{12}$**



## Templating








# Organic Cation Exchange Resin

**Linear Hydrocarbon Chain - Polystyrene**



**Cross Linker - Divinylbenzene**

**Functional Groups** –  $\text{SO}_3^-$ ,  $\text{COO}^-$ ,  $\text{PO}_3^{-2}$ ,  $\text{AsO}_3^{-2}$ ,  $\text{SeO}_3^-$

## Cross Linking

- Swelling
- Regulates Pore Size – Ion Mobility
- Randomness in crosslinking produces disordered structure



## Ion Exchange



### General Remarks

- Reversible Reaction
- Maintain Charge Neutrally
- pH Independent - Strong Acid Functional Group –  $\text{SO}_3^-$
- pH dependent - Weak Acid Functional Group –  $\text{COO}^-$
- Number of groups determined exchange capacity equivalents/volume
- Cation Selective  
Valence –  $\text{M}^{+3} > \text{M}^{+2} > \text{M}^{+1}$   
 $\text{Ba}^{+2} > \text{Pb}^{+2} > \text{Sr}^{+2} > \text{Ca}^{+2} > \text{Ni}^{+2} > \text{Cu}^{+2} > \text{Zn}^{+2} > \text{Mg}^{+2} > \text{UO}_2^{+2}$



## **Procedure - Ion Exchange**

1. 0.1-0.3 M Salt Solution –  $\text{ZrOCl}_2$ ,  $\text{MgCl}_2$ ,  $\text{AlCl}_3$

2. Dowex 50x4 Beads -  $\text{SO}_3^-$

3. Ion Exchange Time  $\geq 18$  Hrs.

4. Liquid/Solid Separation


5. Wash

6. Calcination

1. Single Step  $\rightarrow \geq 6^\circ\text{C}/\text{min} - 600-900^\circ\text{C} - \text{Air}$

2. Double Step  $\rightarrow 800-1000^\circ\text{C} - \text{Inert}$


$\rightarrow \geq 6^\circ\text{C}/\text{min} - 800-1000^\circ\text{C} - \text{Air}$









## Process Variables

- Calcination Heating Rate  $< 6^{\circ}\text{C}/\text{min}$
  - Ion Exchange Time  $< 18$  Hrs.
- ↑**
- Defective Spheres**









# Single Step Calcination





# Double Calcination





## ZrO<sub>2</sub> – Step 1 - Inert





# Double Calcination





ZrO<sub>2</sub> – Step 2 – Air





# MgO/Al<sub>2</sub>O<sub>3</sub> Spheres


Single Step Calcination







## MgAl<sub>2</sub>O<sub>4</sub>/Y<sub>3</sub>Al<sub>5</sub>O<sub>12</sub> Spheres



**MgAl<sub>2</sub>O<sub>4</sub>**

Phase Formation


● 1050 °C 12 hrs.

● 600 °C 5 hrs.

Molar Ratio

AlCl<sub>3</sub>/MgCl

2/1



**Y<sub>3</sub>Al<sub>5</sub>O<sub>12</sub>/Y<sub>4</sub>Al<sub>2</sub>O<sub>9</sub> minor**

Phase Formation

● 1200 °C 48 hrs

● 1200 °C 12 hrs

● 1150 °C 12 hrs

● 600 °C 6 hrs

Molar Ratio

AlCl<sub>3</sub>/Y(NO<sub>3</sub>)<sub>3</sub>



5/3



# Hollow $\text{TiO}_2$ Spheres

2,4- pentanedione  
 $\text{Ti}(\text{OC}_3\text{H}_7)_4$   
Isopropanol

Drip



Coated Beads

•Solid/Liquid Separation



•Air Dry

•Calcine -  $\geq 6^\circ\text{C}/\text{min}$  -  $600\text{-}800^\circ\text{C}$  - Air

2,2,4-trimethyl pentane  
Span 80





# Hollow $\text{TiO}_2$ Spheres





# Al<sub>2</sub>O<sub>3</sub> Coated ZrO<sub>2</sub> Spheres

## Single Step Calcination



### Phase Formation

- 1300 °C 12 hrs.
- 1200 °C 12 hrs.
- 1100 °C 12 hrs.
- 600 °C 5 hrs.



## Summary

- Ion exchange using cation exchange beads can be used as shape forming template to make simple and complex oxides.
- Ion exchange method produces porous ceramic spheres with a unique structure; Inner sphere surrounded by a outer sphere.
- Porous spheres contained elongated pores with a pore width of 0.5 – 3  $\mu\text{m}$ .
- Calcination rate and ion exchange time are important process parameters.
- Cation exchange beads can be utilized as a micro-reactor to form hollow ceramic spheres.
- Cation exchange bead size regulates the pore size of the hollow ceramic sphere.
- Composite particles can be formed by combining both templating methods.

<b>Conference:</b>	27TH ANNUAL COCOA BEACH CONFERENCE AND EXPOSITION ON ADVANCED CERAMICS & COMPOSITES	<b>Add Record</b>
<b>Sponsor:</b>	THE AMERICAN CERAMIC SOCIETY	<b>Save Record</b>
<b>Location:</b>	COCOA BEACH, FLORIDA	<b>Delete Record</b>
<b>Start Date:</b>	01/26/2003	<b>Print Record</b>
<b>End Date:</b>	01/31/2003	<b>Close Form</b>